

# **Aropec SWIM BUOY**

## **USER MANUAL**

1. First, ensure that the buoy is deflated. Open the bag and place your belongings inside.
2. To close, fold the closure strip and roll it down to the marked area (a total of 3 times).
3. Snap the plastic buckles together.
4. Loosen the cap for inflation, inflate with your mouth, and securely twist the cap back on. Repeat on the other side.
5. Adjust the strap so that it fits comfortably around your waist.
6. To deflate the buoy, loosen the deflation cap.

This equipment is not a life-saving device and is intended for experienced swimmers. Before each use, submerge the bag in water and check for leaks. Store in a dry place, away from sharp objects.



## **SPECIFICATIONS**

- Durable nylon material
- Handles on both sides for easy holding
- Double air chambers for maximum buoyancy and safety
- Boston-type combination valves to prevent air leakage after inflation (one valve with separate caps for inflation and deflation)
- Safety whistle built into the plastic buckle
- Dimensions: 36 x 70 cm
- Volume: 28 liters