

AQUASURE - Glue and sealing material for neoprene repairs

Warning: Flammable, harmful vapors – see back label.

For flexible repairs of wetsuits, drysuits, and all neoprene products.

Repairs, waterproofing, sealing, abrasion protection—has hundreds of uses!

AQUASURE – Flexible urethane rubber for any repair.

It bonds hundreds of household items as well as sports equipment.

It repairs wetsuits, drysuits, water sports equipment, and many other items!

INSTRUCTIONS FOR NEOPRENE REPAIRS:

Clean the damaged area with Cotel-240 or a solvent (such as paint thinner, nail polish remover, or a similar product). Trim any loose fibers. Non-fabric surfaces should be roughened with sandpaper and then cleaned. Apply the adhesive directly from the tube, or use a knife or a flat-ended stick. Press the surfaces together and leave them to bond overnight. Avoid contact with other surfaces. Most repairs will fully bond overnight (10-14 hours). For more demanding repairs, wait even longer. Use Cotel-240 accelerator to speed up the curing process (2 hours or less).

HOLES AND CRACKS:

Create a backing with removable tape. Fill the hole up to 0.6 cm past the edge with AQUASURE. Remove the tape once the repair has dried.

SEAMS:

Apply a layer of about 1.5 cm, ensuring it overlaps the edges of the seams by at least 0.6 cm. For fabric, gently press the bonded surfaces together to allow the material to absorb the adhesive.

Heavily Worn Areas:

Use a knife to apply a thick layer, creating a flexible, wear-resistant area.

WARNING:

Fully dried Aquasure adhesive becomes very slippery when wet. To add extra traction to footwear, sprinkle the surface 30 minutes after applying the Aquasure, while it is still not fully dry.

STORAGE:

Squeeze the contents towards the neck of the tube. Keep the cap clean and tightly closed. Store in a cool, dark place, and to extend its shelf life, you can store the tube in the freezer. To thaw or make it easier to squeeze out the contents, immerse the tube in warm water for 15 minutes.

Contains toluene. Use only in a well-ventilated area. Avoid prolonged inhalation of fumes. Do not use near an open flame. If swallowed, do not induce vomiting. Seek medical attention immediately. Avoid contact with skin and eyes. Keep out of reach of children.

USE FOR:

Inflatable toys * rubber snorkel gear * tent seams * tarps and tarp windows * fishing and hunting boots (all types) * underwater hockey equipment * rain gear * inflatable boat bottoms * leather and rubber boots * worn athletic shoes * water skis and snow skis * life jackets * fiberglass products * vinyl covers and many other items!

Use Aquasure only according to the provided instructions. Test repaired items before use. No warranty is provided with the purchase of this product.